


SMART Board® MX



Digital whiteboard. Web browser. Screen sharing. The SMART Board® MX series with iQ has all the essentials educators need for bringing the devices students love into any learning environment. The SMART Board MX series with iQ is a great value for schools that need an interactive display on a budget.


Front control panel

The front control panel includes buttons for turning the display on and off, selecting the video source, opening the display's settings, freezing and unfreezing the screen, and controlling the volume.



Front connector panel

The front connector panel includes connectors for USB drives and other devices and a computer or other input source.




Viewing a connected computer's input

1. Connect a device to the display's HDMI 1, HDMI 2, HDMI 3 or VGA connectors.

NOTE

To enable touch control of the device, connect a USB cable to the associated USB port.

2. Press **Input**  on the front control panel.

The Input selection menu appears.


NOTE

Inputs with devices connected are blue, and inputs without a connection are black.

3. Tap the input you want to view.

The display looks for a connection, and the computer's desktop appears on the display's screen.

Switching to the iQ experience

1. Press **Input**  on the front control panel.

The Input selection menu appears.

2. Tap **OPS**.

The iQ experience appears on the display's screen.

Using the Home screen

You can also open Screen Share, the Files Library and settings from the Home screen.


To show the Home screen

Tap the Home button .

Whiteboard

Using Whiteboard, you can write and erase notes on the display just as you do on a traditional dry erase board. You can also save your notes for later reference and share them using the SMART kapp® app.

To start a Whiteboard

Open the Apps Library and tap **Whiteboard** .

To write in digital ink

1. Pick up a pen.
2. Use the pen to write in digital ink.

SMART Board MX

To erase digital ink

Move your fist or palm over the digital ink you want to erase.



To pan

Press the screen and move your finger left or right.

TIP

You can use the following tools during your Whiteboard session:

	Return to the previous screen.
	Change the pen type, ink width, and ink color
	Connect your smart phone or other mobile device to the display using the SMART kapp app.
	Disconnect your smart phone or other mobile device.
	Save snapshots of the whiteboard to your smart phone or other mobile device.
	Save all notes in the Files Library and clear the Whiteboard.

SMART Notebook Player (education models only)

Use SMART Notebook Player to open, view and interact with [SMART Notebook software](#) files. Notebook Player makes it easy to present SMART Notebook files and play activities on the display.

You can also install the Notebook Player app on your iOS device to view and control SMART Notebook files from the device.

To open SMART Notebook files stored on a USB drive

1. Copy the SMART Notebook files from your computer to the USB drive.
2. Insert the USB drive into one of the USB receptacles on the front connector panel. See *Front connector panel* on the previous page.
3. Open the Files Library.
4. Tap **USB Files**.
5. Select the file you want to open.

To open SMART Notebook files using Share To Board

1. Open the Files Library.
A four-digit code appears.
2. On a computer, open the SMART Notebook file you want to share and select **File > Share**.
3. Click **Share with a SMART Board**.
4. Click **ADD BOARDS**, enter the four-digit code that appears on the display, and then click **Connect**.
OR
Select the display you want to share the file with, and then click **Share Now**.
5. On the display, select the file's thumbnail to open the file .

To open SMART Notebook files using Print to Board

See [Share to the Notebook Player app](#).

TIPS

- Move between pages and documents by selecting the **Page Sorter** button at the bottom of the screen.
- From the Home screen, tap **Files Library** to select a different document.

Browser

You can use Browser to view web sites on the display.

To use Browser

1. Open the Apps Library and tap **Browser** .
2. Use Browser as you would use a web browser on your computer or mobile device.

Screenshots

When using the Browser app or Screen Share app, you can write or draw on an annotation layer and save the screenshot to the Files Library.

To write or draw on an annotation layer

1. Pick up one of the display's pens.
2. Use the pen to write or draw in digital ink.
3. Tap **Close** or **Back** in the command bar.
4. Tap **Save** to save the screenshot in the Files Library.
OR
Tap **Discard** to discard the screenshot and return to the app.

SMART Board MX





To open a saved screenshot

1. Open the Files Library.
2. Select a screenshot by tapping the screenshot's tile.

Screen Share


You can share content from computers and mobile devices on the display wirelessly using Screen Share.

Screen Share supports the following devices:


	Chromebook™ laptops, using Google™ Cast Chrome™ browser extension
	Windows® computers, using Miracast*, Google Cast Chrome browser extension or AirParrot
	Mac computers and iOS devices, using AirPlay
	Android™ devices, using Cast Screen

* Windows 10 and Windows 8.1 operating systems only

To use Screen Share

1. Show the Home screen and tap **Screen Share** .
2. Share the computer or mobile device's screen following the instructions in [Using Screen Share](#).

Cleaning up the display

After you've finished using the display, show the Home screen and tap **Clean Up**  to clean up the display for the next user.

More information

For more information about the SMART Board MX series interactive displays, browse to the following page or scan the QR code.

<https://support.smarttech.com/docs/redirect/?product=smartboardmx>



For more information, visit smarttech.com/smartroom
For more training, visit smarttech.com/trainingforbusiness

© 2018 SMART Technologies ULC. All rights reserved. SMART Board, smarttech, the SMART logo and all SMART taglines are trademarks or registered trademarks of SMART Technologies ULC in the U.S. and/or other countries. All third-party product and company names may be trademarks of their respective owners. Contents are subject to change without notice. 12/2018.

Was this document helpful?
smarttech.com/docfeedback/171345

smarttech.com/kb/171345