Addendum to the SMART Board™ 600i5 Interactive Whiteboard System User's Guide

Changing your projector's aspect ratio for use with your SMART Board 690 interactive whiteboard

Before aligning the projector image on your SMART Board™ 690 interactive whiteboard, you must change the native aspect ratio on your SMART UF75w projector to 16:9. You don't need to perform this step with any other model of interactive whiteboard.

> ⚠ **CAUTION**
>
> Changing other settings in the projector's service menu could damage or affect the operation of your projector and invalidate your warranty. See the "Accessing the Service Menu" section in the *SMART Board 600i5 Interactive Whiteboard System User's Guide* (smarttech.com/kb/154549) for more information.

To change the aspect ratio of your projector

1. Turn on your projector.

2. Quickly press the following buttons on the remote control to access the service menu: **Down**, **Up**, **Up**, **Left**, **Up**.

3. Scroll to the *WXGA_720P_MODE* field.

4. Press **Right** once on your remote control, or until *16:9 aspect ratio* appears.

5. Scroll to the *Exit* field, and then press **Enter** on the remote control to exit the projector service menu.

---

www.smarttech.com/support   www.smarttech.com/contactsupport

SMART™