


SMART Board® GX interactive display


Need more help getting started?
Check out our additional resources.



Turn on the display

To wake the display, press the Power button  on the front control panel.

To put the display into Ready mode, press the Power button  again.





Get connected

Connect your computer with a single USB-C cable, or use both an HDMI cable and USB cable to display your computer and to enable touch.

Change the input

After connecting your computer:

1. Open the Toolbar by tapping one of the side Toolbar buttons  on either side of the screen.
2. Tap the Input  icon.

The Common Settings dialog appears. Tap the input you want to display on the screen.

Use touch

Open and close applications, meet with others, create or edit documents, visit websites, interact with media, and more directly on your display with multiple points of touch.

- Ensure your device is connected with the correct cables.
- Write or draw in digital ink by picking up the pen.
- To erase, use the back of the pen, or move your fist or palm over the ink.
- Tap or press and hold to select.
- Use one finger to pan, or two fingers to zoom in/out and rotate.



Write & save with digital ink

With SMART Ink installed on your connected PC, you can write with digital ink into PDFs and Microsoft Office files and over applications, browsers, and connected video sources.

- Move notes, erase, or even convert notes to text.
- Save your notes into PDFs and Microsoft Office files.

Download SMART Product Drivers and Ink here:

support.smarttech.com/docs/redirect/?product=DRINK