


Get started with the RX Display


GET TO KNOW YOUR RX DISPLAY



Optional:
Customizable Tool Explorer
Stamps and/or Cubes



Use this checklist to explore all of the new features of iQ 4.




Get started with the RX Display



MAIN NAVIGATION BAR

The global navigation bar stays in place along the bottom of the display. It will automatically hide when needed and allow you to switch seamlessly between applications. Swipe up from the bottom to access in any application.



*These four spots on the navigation bar can be customized by removing and adding new applications for your unique needs.



HOME SCREEN

- Tap the **Sign-in icon** to explore new ways to sign in
- Locate the “**Recent Files**” menu
- Locate the “**Favorite Files**” menu
- Find the **navigation bar** at the bottom of the screen
- Long-press, hold and move an icon to explore customization options
- Find the **Google Search Bar** under the clock
- Search for a website that you work with in your classroom



CHROME BROWSER

- Pick up your **pen** and begin writing in the browser window
- Locate the **sign-in** option in the browser - this provides access to your favorites and bookmarks
- Make a frequently visited website a **bookmark** by clicking on the three dots and selecting “add to home screen”
- Tap the **Home button** located on the navigation bar

Get started with the RX Display



ACCESS FILES

- When signed in with a Google Account, tap the **Files Library** icon to open your files
- For lessons in a OneDrive account, launch the OneDrive app to access



CLASSROOM TOOLS

- Tap the **Toolbox** icon to launch the classroom tools menu
- Tap the **Spinner** tool to open
- Resize** classroom tools by tapping, holding, and dragging the bottom right corner
- Customize** classroom tools by tapping the pencil icon




APPS

- Tap the **“Google Play Store”** icon to launch
- Search for an education app of your choice
- Tap to download
- Tap the application to launch



SCREEN SHARE

- Tap the **purple** SMART Mirror icon on the display to launch the application
- Open the browser on your laptop and enter **smartmirror.link**
- Enter the code from the panel to the smartmirror.link tab; enter your name
- On the board, select your name to be invited to present; follow the prompts to present your content



The **iQ 4 Whiteboard** is designed for ease of use to encourage active learning and simplify your workflows.

Let's spend some time exploring the iQ 4 Whiteboard.

Get started with the RX Display



WHITEBOARD

- Locate the blue **Whiteboard app** and tap to open
- Pick up a **pen** and start writing
- Tap the **pen icon** in whiteboard to change pen type/color
- Ask a colleague to pick up the other pen and **write simultaneously**
- Use your **palm to erase** ink while the other person is still writing
- Tap the **insert text** icon and use the on-screen keyboard to type
- Add a **ready-made resource** - tap the "+" icon on the menu bar. Choose a manipulative or graphic organizer; tap to add.



WHITEBOARD - CONNECT STUDENTS

- Tap on the "**people**" icon in the toolbar. Tap on "**Start Session**".
- Participants enter "**www.hellosmart.com**" in a web browser on another device.
- Select "**Join as Guest**". Enter the **class code** from the whiteboard and your name.
- Select "**Join**". Lesson content will now load on the device.
- Tap anywhere within the whiteboard to close the "Join Session" window.